

Make certain you have the correct size WeatherCap.

1. PRIOR to installing the WeatherCap you must remove any water or debris that may have accumulated in the opening.

- a) The exhaust opening may be cut square or at an angle up to 45°
- b) Make certain the pipe surface which will contact the Cap is clean and smooth.
- c) Paint or other surface coatings must be fully cured.

2. Installation for sizes ½" thru 4"


- a) Install the lanyard first. Slip it onto the pipe and slide the collar down the pipe 1 to 2 inches.
- b) Place the Cap on the pipe above the lanyard.
- c) Slide the Cap down onto the pipe about 1 inch.
- d) Slide the lanyard up the pipe until it almost touches the Cap.

3. Installation of 5" thru 24"

- a) Place the Cap on the pipe. Slide the Cap down onto the pipe about 1 inch.
- b) Place the zip tie through the loop at the end of the strap attached to the Cap. Wrap the tapered end of the zip tie around the pipe and slip the end of the tie into the slot at the other end of the zip tie. Draw the zip tie snug; do not cinch tight yet. Slide the zip tie up until it is next to or touching the Cap.
- c) Cinch the zip tie tight to avoid any further movement and cut off excess zip tie.

If the over pressure device activates, the WeatherCap will "pop" off the pipe and must be reinstalled:

- a) Inspect the Cap and replace if damaged.
- b) Inspect the stack / pipe for liquid or debris accumulation and remove any fluids and debris.
- c) Reinstall the Cap as noted above.



Correct Installation



Incorrect Installation

WeatherCaps Fit the OD Dimensions of Schedule 40 Pipe

Part No.	Fits Schedule 40 Pipe	OD Inches (Pipe)
wcl0.5	1/2"	0.840
wcl0.75	3/4"	1.050
wcl1	1"	1.315
wcl1.25	1 1/4"	1.660
wcl1.5	1 1/2"	1.900
wcl2	2"	2.375
wcl2.5	2 1/2"	2.875
wcl3	3"	3.500
wcl4	4"	4.500
wcl5	5"	5.563
wcl6	6"	6.625
wcl8	8"	8.625
wcl10	10"	10.750
wcl12	12"	12.750
wcl14	14"	14.000
wcl16	16"	16.000
wcl18	18"	18.000
wcl20	20"	20.000
wcl24	24"	24.000

Scientific Linings & Coatings, Inc.

Email: Admin@weathercap.com

Website: www.WeatherCap.com

Local: 210-525-8333

Fax: 210-340-5354

Toll Free: 1-800-348-2585